

Service Dept.

Complete Worldwide Maintenance Schedules for:-

Golf 2013 →

Golf Variant 2014 →

Golf Sportsvan 2015 →

From V.A.G. Edition 06.2017

- ◆ Air conditioning & traffic conditions usual for passenger vehicles operating on fuel compliant with EN 228 (Petrol).
2013 yr ->, PR No's. QI4, QI7, Fixed service.
2013 yr ->, PR No. QI6, Flexible service.

This Service Date:_____

Km/Miles:_____

Car Reg.:_____

Oil Change Service.

- Every 15,000km (10,000miles) or 1yr ¹⁾ (QI4, QI7 fixed service).
- Max. 30,000km (20,000miles) or 2yrs ¹⁾ (QI6 flexible service).

- ☐ Drain engine oil & renew oil filter.
- ☐ Brake pads/linings:- check thickness & condition of brake discs, front & rear.
- ☐ Engine oil:- replenish.
- ☐ Service interval display:- reset.

Inspection.

- Every 15,000km (10,000miles) or 1yr ¹⁾ (QI4 fixed service).
- After 30,000km (20,000miles) or 2yrs ¹⁾, then every 30,000km (20,000miles) or 1yr ¹⁾ (QI6 flexible service).
- Every 30,000km (20,000miles) or 2yrs ¹⁾ (QI7 fixed service).

- ☐ Horn:- check function.
- ☐ Headlight washer system:- check function.
- ☐ Front Lighting:- check function.
- ☐ Static cornering light (cornering lighting):- check function.
- ☐ Automatic headlight control:- check function.
- ☐ Rear lighting:- check function.
- ☐ Windscreen wash/wipe system:- check function & spray jet settings & adjust if necessary; check for damage.
- ☐ Wiper blades:- move blades to service position & check for damage; check park position & adjust.
- ☐ Engine & components in engine compartment:- inspect for leaks & damage (from below).
- ☐ Gearbox, final drive & drive shaft boots:- visual check for leaks & damage.
- ☐ Removable original towing bracket:- check
 - If provided.
- ☐ Tyre pressure:- check.

¹⁾ Whichever occurs first.

- ☐ Tyre mobility set:- check for damage & use.
- ☐ Tyres:- check condition & wear pattern of tyre, record tread depth.
- ☐ Oil level:- check.
- ☐ Battery &, if fitted, second battery:- check with battery tester.
- ☐ Engine & components in engine compartment:- inspect for leaks & damage (from above).
- ☐ Brake fluid level (dependent upon brake pad/lining wear):- check.
- ☐ Cooling system:- check frost protection & coolant level.
- ☐ Window wash/wipe system: check anti-freeze protection:- replenish washer fluid.
- ☐ Headlight adjustment:- check & adjust if necessary.
- ☐ Tyre Pressure Loss Indicator:- calibrate after tyre pressure has been corrected.
- ☐ Carry out road test.

Extended Scope of Inspection (applies only in conjunction with regular inspection).

After 60,000km (40,000miles) or 3yrs ¹⁾, then every 60,000km (40,000miles) or 2yrs ¹⁾ (QI4, QI6, QI7 service).

- ☐ Interior lights in headliner, luggage compartment, & glove compartment lights:- check function.
- ☐ Sliding/tilting sunroof:- check function.
- ☐ Interior & exterior of body:- visual check for corrosion.
- ☐ Windscreen:- visual check for damage.
- ☐ Poly V-belt:- check condition.
- ☐ Swivel joints, axle mountings, couple rod bearings, & anti-roll bar rubber mounting:- visual check for damage.
- ☐ Track rod ball joints:- check clearance, firm seating & boots.
- ☐ Brake system:- inspect for leaks & damage.
- ☐ Exhaust system:- visual check for leaks, firm seating & damage.
- ☐ Underbody:- visual check for damage to undercoating, underbody covers, routing of lines, plugs.
- ☐ Front & rear coil springs & rubber buffers:- visual check for damage.
- ☐ Sunroof:- check function, clean guide rails & lubricate with special grease.

Additional Work, Dependent on Time & Mileage.

Air Filter.

Every 90,000km (60,000miles) or 6yrs ¹⁾.

- ☐ Air Filter:- clean housing & renew filter element.

Brake Fluid.

3yrs after initial registration, then every 2yrs.

Every 2yrs (Only markets outside Europe & with fixed oil change intervals).

- ☐ Brake & Clutch System:- change brake fluid.

Dust & Pollen Filter.

Every 60,000km (40,000miles) or 2yrs ¹⁾.

- ☐ Dust & Pollen Filter (cabin filter):- renew.

Gearbox Oil.

Every 60,000km (40,000miles).

- ☐ Dual clutch gearboxes (DSG) OD9:- change gear oil & filter.

1) Whichever occurs first.

Every 120,000km (80,000miles).

- ☐ Dual clutch gearbox (DSG) OGC:- change gear oil.

Miscellaneous.

Every 3yrs.

- ☐ All-wheel drive coupling (Haldex):- change oil.
- ☐ Front differential lock (VAQ):- change oil.

Multi-purpose Additive for Petrol Fuel.

At every service (affected countries only) (see Table 6).

- ☐ Multi-purpose additive for petrol fuel:- add

Panoramic Sliding Sunroof.

Max. 1yr or 15,000km (10,000miles) ¹⁾.

- ☐ Panoramic sliding sunroof.
 - With colourless special lubricant:- check function & for noise.

After 60,000km (40,000miles) or 3yrs ¹⁾, then every 60,000km (40,000miles) or 2yrs ¹⁾.

- ☐ Panoramic sliding sunroof.
 - If the lubricating paste is grey, the guide rails must be cleaned & greased & the wind deflector must be cleaned.

Particulate Filter.

At 210,000km (140,000miles), then every 30,000km (20,000miles).

- ☐ Petrol engine particulate filter:- check.

Spark Plugs.

- ◆ Petrol compliant with EN 228:-
 - Every 60,000km (40,000miles) or 4yrs ¹⁾.
- ◆ E100 Petrol:-
 - Every 40,000km (27,000miles) or 4yrs ¹⁾.
- ☐ Spark Plugs:- renew.

The next time these completed service items need to be carried out is at:-

Km/Miles:_____ or on this Date:_____

Work carried out by:_____

¹⁾ Whichever occurs first.